


1. Packing List

- | | | |
|-----------------------------|----------------------|------------------|
| 1. Prestigio MultiPhone | 2. AC Adapter | 3. Earphone |
| 4. USB Cable | 5. Quick Start Guide | 6. Warranty Card |
| 7. Legal and Safety Notices | 8. Battery | 9. Pouch |

2. Device Overview

- | | | |
|----------|-----------------------------|---|
| 1 | Vol + \ Vol - Button | Adjust the volume level |
| 2 | Earphone Jack | Earphones connection. |
| 3 | USB port | Micro USB cable connection. |
| 4 | Menu | Display menu options. |
| 5 | Back | Back to the previous page. |
| 6 | Home | Back to the Home screen. |
| 7 | Power | Turn on/off the device;
Suspend/Activate the device. |
| 8 | Camera | Take photos. |
| 9 | Speaker | Listen to phone calls or music. |



3. Uninstalling the back cover and battery

- Uninstalling the back cover: hold the side of device tightly with one hand and lift up the back cover at its buckle with the other hand.



- Taking out the battery: hold the side of device tightly with one hand and pull up the battery handle with the other hand.

4. Installing the SIM cards and Micro SD card



Insert SIM



Insert SD Card

a. Insert SIM cards

- The slot on the right is card 2 slot for GSM card, the left is card 1 slot for 3G WCDMA card (compatible with 2G card).
- Please make sure the gold contact area on the SIM is facing downwards.

b. Insert Micro SD card

- To insert a Micro SD card, place the card connector towards the front side of the device and the printing side of the card towards the rear side of the device.
- To remove the micro SD card, pull the card out of the slot.

5. Charging

- Insert one end of USB cable into the USB port on the device and plug the power adapter to the electrical socket.
- Normally it takes approximately 3.5 hours to fully charge the device. Operating the device while charging with the AC adapter may extend the charging time.



Notice: If you don't use your phone for a long time, it will gradually discharge. Please charge it first before your next use or charge the phone every 3 months even you don't use it.

6. Power on/Sleep Mode/Power off

- Press and hold the **Power Button** for a few seconds. It will automatically enter the **Home** screen after start-up screen.

- Press the **Power Button** once to enter sleep mode and press it again to awake the device.
- Press and hold the **Power Button**, and then tap on **Power off** to power off the device.

Technical Specifications

Processor	MT6577 Cortex A9 Dual Core at 1.2 GHz
Memory	512MB DDR2 RAM + 4GB eMMC, Micro SD slot supports up to 32GB
OS	Android 4.0 (Ice Cream Sandwich)
Display	5.0" WVGA TFT-TN LCD, Capacitive multi-touch
Resolution	800*480 WVGA pixels
Band	WCDMA + GSM (UMTS:900/2100MHz; GSM:850/900/1800/1900MHz)
Interfaces	USB 2.0, Micro SD (micro SDHC/SDXC compatible)
Communications	WiFi (802.11 b/g/n), 3G
Battery	2300mAh Polymer Li-ion battery
Dimensions	148.5*79*10.5mm (L x W x H)
Weight	199g

As the Prestigio products are constantly updated and improved, your device's software and hardware may have a slightly different appearance or modified functionality than presented in this Quick Start Guide.



Prestigio hereby states that this Smartphone complies to basic requirements and another relevant regulations given by the EU directive 1999/5/EC. Full version of the declaration of conformity is available on <http://www.prestigio.com/compliance>.